

Installation Instructions For New Construction Single Hung, Double Hung, Sliding And Picture Windows.

Window Opening

The rough opening must be plumb, level, square and 1/2" larger than the window size in width and height, not including the nailing fins (See fig.1). Close and lock the sash to aid in keeping the window square during installation. **Note:** Install sill flashing before the window is installed (refer to "Flashing" below). Apply a 3/8" continuous bead of silicone caulking to the interior surface of the nailing fin, covering the holes in the fin, to seal the window's fin to the sheathing or house wrap. If the rough opening is larger than the window unit by more than 1/2", also apply the caulk to the sheathing or house wrap making sure the bead is no more than 1/4" from the edge of the rough opening, so that it is covered by the nailing fin when the window is installed.

Setting Shims

The sill of the window must be supported in a straight and level position, with shims at all locations where the jamb, intermediate jamb, or the stiles of a slider meet the sill. (See fig. 2A & 2B) Place 1/4" shims on the sill plate of the window opening spaced as described above. Multiple twin or triple windows should have a shim under each mullion, intermediate jamb or the center stiles of sliders. (See fig. 2A & 2B)

Setting Window

Set window on the shims and adjust side clearance to be equal on both sides. Tack one upper corner of the nailing fin to keep the window in place. Check the sill with a level and adjust the shims as required to level sill. Re-adjust side clearance if necessary. Shims must be cut to exact thickness to fit snug and not fall out. Do not force shims into place, possibly pushing the sill upward out of level. Shim both sides of window as needed to assure window is plumb and margins are equal. (see fig. 2A & 2B) Measure window diagonally, from bottom left corner to top right corner and from bottom right corner to top left corner to insure it is square. If the above has been done correctly the width across the top, middle and bottom of the window will measure the same. The wool pile clearance between the sash stile and jamb mainframe should be equal. The meeting rail and lock rail should align evenly, with parallel sight lines. The window locks should engage smoothly.







FIG.3, EXTERIOR VIEW



Nailing Windows Fins

Use stainless or galvanized steel roofing nails, long enough to penetrate studs a minimum of 1".

Nail the entire perimeter of the nailing fin to the sheathing using every other slotted hole at minimum on single windows. Multiple windows twins & triples should be nailed in every slotted hole.

Nail the fin snug but do not "sink" the nails. Nailing should be just tight enough to hold window but not stop the movement of the "Frame-Work" underneath during expansion and contraction. Make sure the head and sill are NOT crowned up or down, or the jambs bowed in or out.

Flashing

Use self adhesive flexible flashing a minimum of 4" wide which has a self-adhering surface on one side, approved for use on vinyl, wood & other substances such as house wrap. This flashing material must meet a minimum water resistance of 24 hours in accordance with ASTM-D779.


(See fig. 3) Sill flashing should already be applied prior to window installation and extend beyond the sides of the window nailing fin at least 2". Now Apply jamb flashing over the jamb-nailing fin, continuing over and beyond the sill flashing, 2" below. Apply head flashing similarly extending 2" past either side of the jamb flashing, to complete the window flashing detail.

Install batt insulation between the window and rough opening. It is very important that these openings are not "over stuffed" and warp the frame. Do not use expanding foam. Doing so will void warranties.

Cautions

- Remove or cut ventilation holes in plastic shipping wrap if windows are not installed immediately.
- Do not lay windows flat or store in the sun. The heat will shrink the plastic wrapping and warp the frame.
- Do not caulk or plug weep holes.
- Protect vinyl sill from traffic and damage.
- Protect the window during construction and plastering.
- Do not drill into or through the sill of the window.
- Do not lift window by top of frame, only by jambs.

Note: The manufacturer's warranty can be voided if these instructions are not followed.* If special applications are needed during the installation, you must contact the manufacturer for approval.



Please call
our hot line
1-708-532-7330
for any installation
help that you
might need.